Prompter People™

Ultralight Presidential




Setup guide Ultralight Presidential



Attach the teleprompter glass to the glass clamp. Slide the glass into the slot and and gently turn the finger knobs so the glass is firmly held in the clamp. Do not over-tighten as you might break the glass.





Place the glass and clamp onto the top of our stand. Make sure the lower knob is loosened enough that the top of the stand goes in.





Tighten the lower glass clamp screw to secure the clamp to the stand.

Setup guide Ultralight Presidential



Screw the stand clamp onto the bottom of the iPAD/tablet cradle.





Fit the iPAD/tablet cradle assembly onto the stand pole and tighten the clamp until it securely holds on the stand. The iPAD/tablet cradle should be under the glass and on the same side of the pole so the iPAD or tablet can reflect into the glass.



Setup guide Ultralight Presidential



Place your iPAD into the cradle. There are screws on the underside of the cradle that allow you to adjust the arms so they hold the iPAD corretctly.

The iPAD/tablet cradle assembly has an articulated arm; when it's black knob is loosened you can position the cradle and iPAD. In normal use the knob is kept tight. The arm should be adjusted so the iPAD/tablet is facing straight up and is level.





The angle of the glass can be adjusted for best viewing angle, and the stand can also be adjusted for height. For adults the stand should be adjusted so the glass is 5 feet or more off the ground. Then you can fine tune the angle for best reading by standing at the reader's position and using the large knob on the glass clamp to fine-tune the reading angle.

7

Now just use your teleprompter app to import your script, and your controller to control the speed and stop/start. The iCUE teleprompter app is available on the Apple app store. Android teleprompter apps are available at Google Play.

Congratulations on assembling yourUltralight Presidential teleprompter. Feel free to contact us if you have any questions. www.prompterpeople.com +1-408-866-9100