


## Flip-Q Wireless Mouse, Remote, and Keyboard Setup

### Default Action Assignments


Flip Q ships with default keyboard controls. Only import an included new **“Action Assignments”** if you are setting our wireless remote, or your own remote or mouse. Wireless remotes and mice require Action Assignments to be set. Please see below to import an Action Assignments.

\*Action Assignments cannot be set for the Control Shuttle. To set up Control Shuttle please view our Shuttle Express Setup Guide.

1. Open FlipQ. Navigate to your top menu and select “File”  
From the “File” menu select “Action Assignment.”



1. Select “Action Assignment”




2. Select “Import”

2. The “Action Assignment” window will open as a pop-Up widow.  
From the Action Assignment pop-up widow select “Import”

3. A finder or explorer window will pop-up.  
From this window navigate to your Flip-Q folder and find your “Action Assignment” folder. Navigate to either Mac or PC. Double click on the Action Assignment you want to set. You will be taken back to the Action Assignment window , select “OK” to set your new new Action Assignment.

File Extension Mac: “.ctpmac”

File Extension PC: “.ctp”




3. Select the “Action Assignment” that you are operating.

## Flip-Q Wireless Mouse, Remote, and Keyboard Setup


### Customizing Action Assignments

Flip Q ships with default keyboard controls. Only reassign **“Action Assignments”** if you are setting up a wired or wireless remote, mouse, or want to customize keyboard controls. Wireless remotes and mice require Action Assignments to be set. Please see below to customize Action Assignments.

1. Open FlipQ. Navigate to your top menu and select **“File”**  
From the **“File”** menu select **“Action Assignment.”**




1. Select **“Action Assignment”**



2. Action Assignment window



2. The **“Action Assignment”** window will open as a pop-Up widow.  
**“Available Actions”** are listed on the left. In the center are the **“Actions”**.  
On the right is **“Change”**

3. Select **“Change”** next to the Available Action you want to change on your wireless remote, mouse, or keyboard.




## Flip-Q Wireless Mouse, Remote, and Keyboard Setup

4. Select “Use Keyboard” or “Use Mouse”  
Remember when setting your mouse or keyboard for this Action Assignment you will not be able to use both at the same time.




5. Once you have selected “Use Keyboard” or “Use Mouse” navigate to the empty box at the bottom of your pop-up window. Click into the empty space.


6. Once you have clicked into the empty space, perform the “Action” on your keyboard, mouse or remote that you wish to set for that “Action Assignment.” The action you’re performing will appear in the empty box.



## Flip-Q Wireless Mouse, Remote, and Keyboard Setup



7. Select "OK" to save your action. Repeat steps 1 - 7 to set and save more editable actions.



8. Select "Reset" to restore FlipQ Factory Defaults Action Assignments. The PrompterPeople Foot Pedal requires default action assignments to be set to function properly.

8. Restore Factory Default Action Assignments

